



## Fizik Saddle Mount - Installation Instructions

**WARNING:** Do not allow threadlocker (e.g. Loctite) to contact the riser, this will void the warranty, as it will weaken the base materials and lead to product failure.

- 1) Remove existing bolts from under the saddle (3mm Hex) and from the AirTag compartment of the saddle mount (2mm Hex).
- 2) *Optional* - Insert activated Apple AirTag into compartment. Silver side facing up.
- 3) Ensure the lid is aligned correctly, with the taper towards the rear.



- 4) The lid should snap into place with a gentle click, then torque the M3 bolts to 1Nm (8.5in-lbs),  
*DO NOT exceed 1.8Nm (9in-lbs).*
- 5) Torque saddle mounting bolts to 4Nm (35 in-lbs) with hex driver,  
*DO NOT exceed 5Nm (45 in-lbs).*
- 6) Install device (e.g. Varia) onto mount by rotating 90 degrees. Secondary retention cable is recommended.
- 7) *Removal* - Remove lid and AirTag may be removed by firmly tapping one end of the mount onto a firm surface, until AirTag has moved enough to be removed by hand.
- 8) Ride and enjoy!

**-Got a product idea?** Let us know, you'll get a discount coupon or a free product if we make it!-

**Warranty Information:** This product is warranted to be free from defects in materials and workmanship for a period of six months from the date of original purchase. During this period, the manufacturer will repair or replace, at its discretion, any defective product. Contact [Support@30mmDesign.com](mailto:Support@30mmDesign.com) for any warranty claims or technical assistance.